

TPMS Configurator Manager Guide

Document version: EN 1.0.0
Update date: 2019-12-18

Content Index

1 Preface	4
1.1 Document Purpose	4
1.2 Reference	4
1.3 Compatibility	4
1.4 Term of use	4
1.5 Document History	5
2. Things before start	6
2.1 Hardware/Software	6
2.2. Configurator Manager folder	6
3. Interface Introduction – start up	7
3.1 Section A: Configurator version	8
3.2 Section B: Basic operation button	8
3.3 Section C: Device status	8
3.4 Section D: Parameter tab	9
3.4.1 Section D_sub: Comms	9
3.4.2 Section D_sub: Schedule	9
3.4.3 Section D_sub: Authorization	10
3.4.4 Section D_sub: IOS	11
3.4.5 Section D_sub: Audios	11
3.4.6 Section D_sub: Geofence	12
3.4.7 Section D_sub: SMS	12
3.4.8 Section D_sub: Peripheral	12
3.4.9 Section D: Behavior	13
3.4.10 Section D_sub: TPMS	13
3.4.11 Section D_sub: Unit Test	14
3.5 Section E: log window	14
3.6 Section F: USB connectivity	15
4. Operation example	15
4.1 How to change APN/IP/Port to device	15
4.2 How to change the data time interval?	16
4.3 How to export the device parameter to an external file?	16
4.4 How to quick set parameter for bath devices?	16
4.5 How to flash the firmware for device?	17

4.6 How to get a correct GPRS command checksum? 17

4.7 How to send a command to device in configurator? 17

1 Preface

1.1 Document Purpose

This document was released to help you understand how to operate configurator manager.

1.2 Reference

This document is supposed to work with other document or program. All related document or program listed below can be found in our online document library.

- [01 Datasheet](#) – device technical specification (.pdf).
- [02 User Manual](#) – A guide to help you understand the feature of the device and command list (.pdf).
- [03 Quick start](#) – IO port connection reference and how to quick start the device(.pdf).
- [04 Protocol](#) – data string from device to server and acceptable SMS/GPRS command(.pdf).
- [04 Configuration Guide](#) – (this document) instruction on how to configure device (.pdf).
- [05 Configuration tool](#)– configurator manager to read/save preset setting to device (.exe).



Online Document Library: [Document online Library](#)

1.3 Compatibility

This document is compatible with the following Totemtek products:

- AT09 2G/3G TPMS version only

1.4 Term of use

Copyright © 2019 Totem Technology Co Ltd All rights reserved. Reproduction, transfer, distribution or storage of parts or all of the contents in this document in any form without the prior written permission of Totemtek is prohibited. Other products and company names mentioned in this document are trademarks or trade names of their respective owners.

If any information you feel that is not correct, please contact our support team: support@totemtek.com;

1.5 Document History

Date	Version	Update
2019-12-18	1.0.0	First release.

2. Things before start

Before you start to connect the device with PC/Laptop, make sure you have below things ready.

2.1 Hardware/Software

- PC or laptop (windows based)
- Device with enough battery (check if the LED is blinking when you power on the device).
- Regulated DC power supply DC 12V/24V (in case device is in low battery).
- USB cable (Purely USB cable): USB cable for android mobile with mini USB interface.

- **.Net framework 4 or above.**

The configurator Manager requires .Net framework component. If you are not sure, you can check control panel → Apps list in your Windows.



Download .Net framework from Microsoft: [Download .Netframework web installer](#)

- **Configurator manager**


The configurator Manager requires .Net framework component. If you are not sure, you can check control panel → Apps list in your Windows.



Download from Totemtek website: [Configurator Manager](#)

2.2. Configurator Manager folder

The content of the folder can refer as below:



GPRSLog: This folder will create automatically once the configurator manager has been set up as a TCP listener to receive data from device.


USBLLog: this folder will create automatically once the configurator is running. Device running log will keep under this folder. Client can send the TXT log under this folder to our support team to diagnose the problems.

TPMS configurator Manager.exe: this is configurator of the device (windows based application).

UsbLibrary.dll: this is library of USB. It should be always kept in the same folder.

This is the initial interface once Configurator Manager is running, if you got any error, please check as below:

- Make sure the .net framework 4 or above has been installed.
- Make sure the UsbLibrary.dll and configurator manager are in the same folder.



This section is the window to display the configurator version (standard/beacon/COM/TP) and version number (4.02).

This section has provided some basic operation buttons and password input window to avoid access without authorization.


This is the device status window. It contains connectivity status, device IO status, power status, device IMEI, firmware version and module number.

This is the most important window; it contains several sub tab in this section. All the desired parameter can be changed in this section.

This section a log display window. The device will save the log continuously into a txt file and also display in the log window.

This is USB connection indicator, the communication between device and PC/laptop relies on the USB connection. So please make sure the connection has been established.

3.1 Section A: Configurator version




Totemtek product comes with several version of the configurator manager, each one is combining with different product, please follow below match pair.

- STD/Standard: AT07 2/ 3/4G, AT09 2G/3G/4G.
- Beacon: AT08, AT20(Solar power unit)
- TPMS: AT09 TPMS
- COM: AT04, AT05
- TP: TP08, TP09


Ver:4.02: This is the configurator version.

3.2 Section B: Basic operation button



- Read from dev: read the setting from device.
- Save to dev: save the setting into device
- Password: entry the password before any operation.
- Initialize: reset to factory setting.
- Reboot: reboot device
- Import cfg file: import the device parameter from a XML file.
- Export cfg file: export current setting into a XML file.

3.3 Section C: Device status



- Device: AT09 TPMS
- Comms module: GSM/3G/4G module name.
- Ver: 1.08 (device firmware version)
- Working mode: device working mode sleep/deep sleep.
- IMEI: GSM module IMEI number.
- RFID/IB: RFID ID number of IButton number.
- ANI 1 – ANI4: the voltage or percentage from analog input
- Cell ID: cell tower ID.

- Cellular CSQ: GSM signal strength (Maximum 31).
- GNSS satellite: (number of GPS/GPS/BEIDOU fixed)
- Lon: longitude
- Lat: latitude
- Data in memory: 3 Axis: (3 axis vibration strength).
- IP/Port: (current target server and port).
- Connect status: (initialize/fail/off).
- Temperature: temperature value from 1 wire interface
- RS232: specific protocol in using on this port
- RS232: specific protocol in using on this port
- RS485: specific protocol in using on this port
- Error: reserved.
- Battery: the internal battery voltage.
- External : external power supply voltage
- DO1~DO4: digital output status of the device (red color is deactivated; green color is activated)
- DI1 ~ DI4: digital input status of the device (red color is deactivated; green color is activated);
- SOS: SOS button (red color is deactivated; green color is activated);
- GPS: GPS antenna status (red color is disconnected; green color is connected);

3.4 Section D: Parameter tab

This is main section where the device settings are changed.

3.4.1 Section D_sub: Comms

Device: AT09
Comms module: M35
Ver: V4.00
Working mode: Normal
IMEI: 867965020468472
RFID/IB: 0000000000000000
ANI1: 0.0v
ANI2: 0.0v
ANI3: 0.0v
ANI4: 0.0v
Cell ID: 27BA0E4E
Cellular CSQ: 13
GNSS satellite: 10
Lon: 11403.51915E
Lat: 2237.77696N

Comms Schedule Authorization IOs Audio Geofence SMS Peripheral Behavior TPMS Unit Test

Comms

UserID: Domain/IP:
 PIN code: Target address:
 GSM Band: Target Port:
 APN: Protocol:
 User Name: Server Response Timeout:
 Password: Heart beat timeout:

- UserID: this ID will replace the IMEI in the GPRS string if it has been set. Normally leave it in blank.
- PIN code: some SIM needs a pin code/password to work normally.
- APN/User Name/Password: APN user name and password.
- Domain/IP: target is domain or IP.
- Target address: domain address or IP address.
- Protocol: TCP/IP, UDP/IP;
- Server Response Timeout: TCP/IP, ACK response time, if no response within the pre-set time, device will send same data again.
- Heart beat time out: Heart beat package (BB) time interval.

3.4.2 Section D_sub: Schedule

Device: AT09
Comms module: M35
Ver: V4.00
Working mode: Normal
IMEI: 867965020468472
RFID/IB: 0000000000000000
ANI1: 0.0v
ANI2: 0.0v
ANI3: 0.0v
ANI4: 0.0v
Cell ID: 27BA0E4E
Cellular CSQ: 15
GNSS satellite: 12
Lon: 11403.51915E
Lat: 2237.77696N

Comms Schedule Authorization IOs Audio Geofence SMS Peripheral Behavior TPMS Unit Test

Schedule

Sending data by Movement or Ignition ON/OFF
 Combined with ignition: ①

Movement Detection
 Ignition Sensor:
 3 Axis Accelerometer:
 Movement detection delay to wake up: Sec

Ignition ON or Moving
 Minimum time: Sec ②
 Minimum Distance: meter
 Minimum veer: degree

Ignition OFF or Stop
 Minimum Time: Sec ③

Sleep/Stop Definitions
 Working mode:
 Sleep Delay: Sec

- Sending data by movement or ignition ON/OFF ①

Combined with ignition: by Movement/By ignition

① is the trigger for ②/③

Caution: ACC+ or DI1+ is the PIN for the ignition connection. If ACC+/DI1+ no connected, device will always use 'by movement'.

- Movement detection

Ignition sensor: on (device in movement status once ignition on).

3 Axis Accelerometer: On (use 3 Axis to detect the movement).

Movement detection delay to wake up

- Sending data by movement or ignition ON/OFF ②

Minimum time: X seconds; (send data in X second interval).

Minimum distance: meter; (send data in Y meter interval).

Minimum veer: degree (send data in Z degree interval).

Each time/distance/veer (X, Y, Z) thread are separately, set as '0' will disable one of them.

If ① has been selected as "by ignition" and ACC/DI1+ has connected, device will start to count once ignition on and X second later will send out 1pcs time interval data, and after Y meter distance, send 1pcs distance data. And if veer change Z degree, it will send out 1pcs veer data.

If ① has been select as "by movement", device will start to count when vehicle moving and X second later will send out 1st data, and after Y meter distance, send 1pcs distance data. And if veer change Z degree, it will send out 1pcs veer data.

- Ignition OFF or Stop ③

Minimum time: X seconds.

If ① has been selected as "by ignition" and ACC/DI1+ has connected, device will start to count once ignition off and X second later will send out 1st data.

If ① has been select as "by movement", device will start to count when vehicle stop and X second later will send out 1st data.

- Sleep/stop Definitions

Working mode: Normal/Sleep/Deep Sleep

Normal: Cellular module and GPS module is normal working.


Sleep: Cellular module working, GPS module shut down.

Deep sleep: Cellular module and GPS module both shut down.

Sleep delay: X seconds

When device stop, device will go to working mode (sleep/deep sleep) if no vibration.

3.4.3 Section D_sub: Authorization



- **Authorize ID:** these are the IDs section for RFID or iButton.
Click 'detect iButton/RFID', it will turn to green. Once the iButton has been activated, the ID will fill in the ID list automatically.
- **Covert.**
The ID print on the RFID is in ASCII code, the configurator required a Hex code. Put in the configurator, it will change to Hex and then save into device.

3.4.4 Section D_sub: IOs

- **Digital input**
IN1+/IN5: on/off; If 'OFF' was selected, this IO will not response for input high/low.
- **Digital Output**
User define: if you want to send SMS to control this output, should select this item.
Off: turn off digital output
RFID/iButton: control by firmware, will reject the command (016) and response 'format error' when you send SMS.
- **Analog input**
On/off: on off the analog input.
Percent: the GPRS string will change to percent instead of voltage itself. Minimum voltage 'L' and maximum voltage is 'H'. the unit is mv, not V. 5000 means 5V.
In this example, maximum level is 5V, and minimum is 0V. if the analog input reading is 2.5V, the GPRS string will send 0050(50%) in the string.

3.4.5 Section D_sub: Audios

- **Authorized monitor phone**
Auto answer: on/off
Phone 1/Phone2/Phone3: Phone number list that device will pick up. All the number out of this list will be rejected.

3.4.6 Section D_sub: Geofence

Device: AT09
Comms module: M35
Ver: V4.00
Working mode: Normal
IMEI: 867965020468472
RFID/IB: 0000000000000000
ANI1: 0.0v
ANI2: 0.0v
ANI3: 0.0v
ANI4: 0.0v
Cell ID: 27BA0E4E
Cellular CSQ: 17
GNSS satellite: 09

Comms Schedule Authorization IOs Audio Geofence SMS Peripheral Behavior TPMS Unit Test

GEO fence

Enter event: ON
Exit event: ON
Radius: 500 meter
Latitude: 11403.51915
Longitude: 2237.77696

- Geofence

Copy the coordinate from Section B directly for the coordinate.

3.4.7 Section D_sub: SMS

Device: AT09
Comms module: M35
Ver: V4.00
Working mode: Normal
IMEI: 867965020468472
RFID/IB: 0000000000000000
ANI1: 0.0v
ANI2: 0.0v
ANI3: 0.0v
ANI4: 0.0v
Cell ID: 27BA0E4E
Cellular CSQ: 14
GNSS satellite: 10
Lon: 11403.51915E
Lat: 2237.77696N

Comms Schedule Authorization IOs Audio Geofence SMS Peripheral Behavior TPMS Unit Test

SMS

Target phone number: 13796358543

GPS antenna cut OFF IN1 ON OFF IN1 OFF OFF
Tow OFF IN2 ON OFF IN2 OFF OFF
External power cut OFF IN3 ON OFF IN3 OFF OFF
Low battery OFF IN4 ON OFF IN4 OFF OFF
GEO IN OFF IN5(SOS) OFF
GEO OUT OFF

- SMS target phone number

ON/OFF: send a SMS alarm to preset mobile number (some carrier required country code, take a test before installation) if alarm has been triggered.

TOW: when device is parking and ignition off, vehicle move out from a 200m.

3.4.8 Section D_sub: Peripheral

Device: AT09
Comms module: M35
Ver: V4.00
Working mode: Normal
IMEI: 867965020468472
RFID/IB: 0000000000000000
ANI1: 0.0v
ANI2: 0.0v
ANI3: 0.0v
ANI4: 0.0v
Cell ID: 27BA0E58
Cellular CSQ: 17
GNSS satellite: 11
Lon: 11403.51915E
Lat: 2237.77696N
Data in memory: 0018
3 Axis: 0021

Comms Schedule Authorization IOs Audio Geofence SMS Peripheral Behavior TPMS Unit Test

Temperature Alarms

Temperature 1 ON Temperature 2 ON
Low: 0 °C Low: 0 °C
High: 50 °C High: 50 °C

RS232

RS232 1 Protocol RFID
RS232 2 Protocol OBD

RS485

RS485 Protocol Camera

- Temperature Alarms

On/off: on/off temperature interface (1 wire).

Low: low temperature to trigger the events.


High: high temperature to trigger the events.

- RS232:

RS232 1 protocol/RS232 2 protocol: binding specific protocol for the RS232 port.


- RS232:
RS485: binding specific protocol for the RS232 port.

3.4.9 Section D: Behavior



- Speed Alarms:
Over Speed: on/off over speed alarm.
Max speed: pre-set value for over speed alarm.

3.4.10 Section D_sub: TPMS



- Tpm data time: 120 seconds (time interval that device send TPMS data to server, in order to save the power for the TPMS sensor, 120s is the minimum).
- Pressure unit: unit switch for KPa/PSI/Bar.
- Receive all sensor data: device will display all received TPMS sensor data in the log window, not only the one listed in device.
- TPMS ID: the sensor ID contains two part: position ID + original ID which print on the sticker. For example, if you want to install sensor '6C0C97FF' to the left side of 1st axle, position ID is 11. So 116C0C97FF should save into device.
- CAUTION:
 1. after all sensor has been stored inside the device, you should '**Read from dev**' again, in this case, all sensor will match with the position icon.
 2. if you want add/delete/change the position of the tyre sensor, '**Read from dev**' is required to let sensor match with position icon on the right side position diagram.

[illegible]

- ### 3.5 Section E: log window

Data in memory:0014

3 Axis:0055
IP/Port:
connect status:Connect OK
Temperature1/2 : 0/0°C
RS232 1:
RS232 2:
RS485:
Error:

Battery:3.83v

SOS

External:0.000v

GPS

DI1

DI2

DI3

DI4

DO1

DO2

DO3

DO4

Log window

GSM Reply: OK
GSM Reply: +QISEND: 1404,1404,0
GSM Reply: OK
GSM CMD: AT+QISEND=0,108
GSM CMD: \$\$0108AA868998030728170|
088040001912170242243800000027BA0E58143100000000.800000002237.7729N11403.5226E001429
GSM Reply: SEND OK
GSM Reply: +QIURC: "recv",0
GSM CMD: AT+QIRD=0,1500
GSM Reply: +QIRD: 14
GSM Reply: \$\$0014AA001400
GSM Reply: OK


☒ Show log:
Clear
Open log folder

- 14 / 17

- **Clear:**
Clear the log in the log window.
- **Open log folder:**
Device will write into a TXT automatically; the file name is current date. These logs are useful information for our support team if your device has problem.

Name	Date modified	Type	Size
20191014.txt	2019-10-14 10:04 ...	Text Document	12 KB
20191125.txt	2019-11-25 5:26 PM	Text Document	267 KB
20191126.txt	2019-11-26 11:06 ...	Text Document	11 KB
20191205.txt	2019-12-05 4:36 PM	Text Document	6 KB
20191212.txt	2019-12-12 4:17 PM	Text Document	1 KB
20191214.txt	2019-12-14 10:13 ...	Text Document	11 KB
20191217.txt	2019-12-17 10:46 ...	Text Document	46 KB

3.6 Section F: USB connectivity




- **USB HID Disconnected**
USB icon will turn to green once the USB connection has been established.



4. Operation example

4.1 How to change APN/IP/Port to device




Read from dev: read the setting from device first. Don't operate anything before you read from device.

APN: change the APN you want.

IP/Port: change the IP and port.


Save to dev: save the setting to device.

4.2 How to change the data time interval?




1. Read from dev: read the setting from device first. Don't operate anything before you read from device.
2. Sending data by Movement or ignition ON/OFF: select the desired trigger 'by movement' or 'by ignition'.
3. Ignition ON or moving: change the data time interval and minimum distance for data and minimum angle.
4. Ignition OFF or Stop: set the time interval when vehicle stop
5. Save to dev: save the setting to device.

4.3 How to export the device parameter to an external file?



1. Read from dev: read the setting from device first. Don't operate anything before you read from device.
2. Change the desired setting.
3. Export cfg file: export the parameter setting file into a XML file.


4.4 How to quick set parameter for bath devices?



1. Import cfg file: load the setting from an external CFG file (XML file).


2. Change the desired setting.
3. Save to device.

4.5 How to flash the firmware for device?




1. Load: load the firmware.
2. Select the correct firmware from folder.
3. Start: start to flash the firmware.

4.6 How to get a correct GPRS command checksum?



1. Entry the command (full command list can be found in our user manual).
2. Click 'GPRS CMD format'
3. The one in gray color "\$\$0024CF000000,016,B,16B" (6B is the checksum) string is complete command with checksum. GPRS command format can be found in our communication protocol.

4.7 How to send a command to device in configurator?



1. Entry the command (full command list can be found in our user manual).
2. Click 'USB' to send the command to device.
3. Configurator manager will pop up a successful window if the command is in correct format.

END