

AT20 3G Quick Start Guide

Ver: EN 1.0
Date: 2019-10-25



Please Make sure you have download below docs before you start:

1. AT20 online document support:


🌐 <https://en.totemtek.com/support/documents/gps-tracker-at20/>
--- User manual, configurator, configuration manual.

2. AT20 online video reference:


🌐 <https://en.totemtek.com/category/blog/video/>




1 Unscrew 8 screw to open the enclosure.




2 Take the base from the top cover.




3 unlock the SIM slot and put SIM inside, SIM metal part face to PCB board.



4 lock the SIM inside the SIM slot.



5 turn on the device and connect device to PC by USB cable , and run configurator.



PIN7
PIN6 Battery switch, disconnect PIN6/7 will turn off the device.

PIN8: DC 12-50V +
PIN5: DC 12-50V -
PIN3: IGN
PIN11: DO1

PIN9: Solar Panel +
PIN4: Solar Panel -

PIN1: 1-Wire
PIN2: 3.3V

PIN10: ANI
PIN12: DI1+

